

Tips to improve performance and extend the life of your 1" Bullnoser™ CMU Corner Router

- Always use the highest standard of safety including breathing, eye, and hearing protection
- Use with any 4" hand held grinder



Step 1: Use a hammer or cup grinder to take the edge off the corner. Try keeping the substrate moist to control dust.

Step 2: Start grinding from the outside edge of the router bit in to avoid over wear at the center.

Step 3: Create a bull-nose finish on all types of CMU either in place (jamb and heads), individually, or laid side by side on a table.



Step 1



Step 2



Step 3

